





PIPE STRAIGHTNESS GAUGE

GUIDE LENGTH (L) CAN
BE CUSTOMIZED

DATA
OUTPUT



application



- Measure inner wall straightness of pipes
- Optional accessory: wireless transmitter part no. **7315-50M** (receiver is needed)

Part No.	Measuring range	inner diameter of measured bore	Resolution	Straightness accuracy	L
2226-400	15.7"	4.0"-9.8"	.0005"/0.01mm	.002"	16.93"