


LUG BACKS


Part No.	For electronic/ dial indicators
7330-L2	2324
	2315
7330-L3	2326-3
	2326-4
7330-L4	2304
7330-L5	2103
	2104
	2109
	2112
	2113
	2115
	2117
	2118
7330-L6	2307
	2326-2
7330-L7	2837
7330-L8	2832



7330-L2



7330-L8



FLAT BACKS

Part No.	For electronic/ dial indicators
7330-F2	2324
	2315
7330-F3	2326-3
	2326-4
7330-F4	2304
7330-F5	2103
	2104
	2109
	2112
	2113
	2115
	2117
	2118
7330-F6	2307
	2326-2
7330-F7	2837
7330-F8	2832



7330-F2



7330-F8

