

ATTENTION: CLOCKWISE
OPERATION ONLY

- Ratchet head
- Torque is preset, to prevent adjustment by mistake during use
- The torque is set at the factory before delivery. Customers can also set the torque with torque adjustment tool (**optional**) and digital torque testers (**IST-TT□□□□, optional**)
- Clockwise operation only



IST-PW125



torque adjustment tool
(optional)

SPECIFICATION

Part No.	Adjustable range *		Accuracy	Square driver (D)	Length	Weight
IST-PW5	10~45lb.in	1~5N.m	±3%	1/4"	6.38"	.55lb
IST-PW10	20~90lb.in	2~10N.m		1/4"	6.81"	.57lb
IST-PW12	20~105lb.in	2.5~12N.m		1/4"	7.24"	.99lb
IST-PW20	30~180lb.in	4~20N.m		1/4"	7.24"	.99lb
IST-PW30	50~250lb.in	6~30N.m		3/8"	8.43"	1.10lb
IST-PW60	9.0~45lb.ft	10~60N.m		3/8"	10.04"	1.23lb
IST-PW125	20~90lb.ft	25~125N.m		3/8"	14.41"	1.74lb
IST-PW200	30~150lb.ft	40~200N.m		1/2"	17.99"	2.64lb
IST-PW340	50~250lb.ft	65~340N.m		1/2"	27.20"	4.32lb
IST-PW500	80~400lb.ft	100~500N.m		3/4"	36.02"	6.17lb
IST-PW650	100~500lb.ft	150~650N.m	±3% (≤500N.m) ±4% (>500N.m)	3/4"	36.02"	6.17lb
IST-PW800	120~600lb.ft	160~800N.m		3/4"	40.55"	11.02lb
IST-PW1000A	150~750lb.ft	200~1000N.m		3/4"	49.61"	13.22lb
IST-PW1000B	150~750lb.ft	200~1000N.m		1"	49.61"	13.22lb
IST-PW1500	200~1100lb.ft	300~1500N.m		1"	63.39"	17.63lb
IST-PW2000	300~1500lb.ft	400~2000N.m	±4%	1"	75.20"	20.93lb
IST-PW3000	400~2200lb.ft	600~3000N.m		1"	79.13"	21.81lb

OPTIONAL ACCESSORY

Torque adjustment tool

IST-36WM-TOOL1 (suitable for IST-PW5, IST-PW10)

IST-PW-TOOL (suitable for all codes except IST-PW5, IST-PW10)

* Adjust to a fixed torque value according to customer requirements before delivery